



User Manual

airtouch.net.au

COOL





HEAT

FRESH /FAN



Modes and functions available depend on your Air Conditioning Unit.

Contents

Getting Started

Quick Start	2-3
Quick Menu & Controls	4-5
Adjusting Airflow for a Zone	6
Controlling Zone Temperature	7
Setting the AC Timer	8-9
Setting a Program	10-11
Turbo Zone	12-13
Setting up Favorites	14-15
Using ITC	16-17
AirTouch App & Integrations	18-19
Advanced System Settings	
AirTouch Android OC Concolo	
Airrouch Android US Console	22
Naming Your Zones	22 23
Naming Your Zones Screen Lock	22 23 24
Naming Your Zones Screen Lock Owner's Name	22 23 24 25
Naming Your Zones Screen Lock Owner's Name Temperature Display	22 23 24 25 26
Naming Your Zones Screen Lock Owner's Name Temperature Display Balancing & Grouping Tables	22 23 24 25 26 27
Naming Your Zones Screen Lock Owner's Name Temperature Display Balancing & Grouping Tables WiFi & Internet Setup	22 23 24 25 26 27 28-29
Naming Your Zones Screen Lock Owner's Name Temperature Display Balancing & Grouping Tables WiFi & Internet Setup Favourite Apps	22 23 24 25 26 27 28-29 30-31
Anrouch Android OS console Naming Your Zones Screen Lock Owner's Name Temperature Display Balancing & Grouping Tables WiFi & Internet Setup Favourite Apps Troubleshooting	22 23 24 25 26 27 28-29 30-31 32-33

Quick Start - Console



Zone Name & Airflow Percentage

Adjust with () and () buttons To rename your Zones see page 23. (Will display Set Point Temperature if you have optional Individual Temperature Control Sensors)

Mode

Cool, Fresh, Heat, Dry & Auto (Depends on unit) System /AC Status

Slider To change the temperature

Fan Speed

AC ON/OFF Quick Operations Push & hold to turn on or off ACs.

Quick Start - Mobile App

Home Screen



Some Settings & Zone names setup on the AirTouch Console will be replicated in the App.

Zones Screen

0 airtouch Lounge ₂r ⊖ 75[%] ⊕ **▶**⊖100%⊕ O Dining Family 9 60% € 9 50% € Josh ⊖ 80% ⊕ O Jess

Quick Menu & Controls

You can access common AirTouch features using the Quick Menu.



Access the **Quick Menu** by tapping on the menu icon \equiv in the top right.



Inside the Quick Menu



Turn On/Off AC

To turn On or Off AC either tap the Power button at the top



Or push and hold the button on the lower right corner

Turn on the first AC if all AC's are off. \ddagger Turn off all AC's if there is at lease one AC on.



Adjusting Airflow for a Zone

Use the \oplus and \bigcirc buttons next to the zone names to increase or decrease the air flow in 5% increments.



Your zone names are on the left of the home screen.

By default, AirTouch lets you control the air volume in % for each zone.

Controlling Zone Temperature

If a zone has ITC installed, it can be controlled by temperature or airflow.

1

Use the \bigoplus and \bigcirc buttons to increase or decrease the set point in an individual zone.

*If a zone has ITC available, the air temperature/ volume will have a rounded border.



To switch to °C temperature display (set point temperature for the zone), tap on the Air Volume %.



The air volume will automatically adjust according to the difference of set temperature and measured temperature in the zone.

NOTE:

If 'Groups lock to temp control' is ticked in Installer Settings, the groups will only have setpoint display.



Setting the AC Timer



The AC Timer function is useful for automatically switching the AC on or off at a given time.

The ON and OFF Timer function can be used in combination or separately for 1 or more AC units.

Quick Timer

Setting the Quick Timer from the Home screen to Turn ON or OFF the Air Conditioning at a chosen time (up to 12 hours)

Turn ON Timer

To Set a Quick Timer to **Turn On the Air Conditioning** when the unit is currently off, Tap and Hold the Power Button and scroll to select your desired **On Time.** The On AC timer icon will appear below the power button.

Turn OFF Timer

To Set a Quick Timer to **Turn Off the Air Conditioning** when the unit is currently on, Tap and Hold the Power Button and scroll to select your desired **Off Time**. The Off AC timer icon will appear below the power button.



Remove Timer

Touch () near the AC home to bring up Timer Setting dialogue. Choose the timer to be removed and touch **Confirm** button to finish.

Advanced Unit Timer Functions

2



Use the **Time** wheel to choose the time for each operation. When a Timer event is scheduled, a Timer lcon will display on the home screen.





Setting a Program

A more advanced version of the Timer function is the Program function, letting you turn the AC

ON or OFF and specify a Temperature for your entire house or individual zones.

Open the Quick Menu and select Programs.

airtouch		U Downstates AD	X
U Lounge Θ	75* ⊕	Favourites	Athenesette
(U) Dining ⊖	100%⊕₽		
● Family ⊖	60* ⊕	U Programs	
🙂 Josh 🖂	50≚ ⊕	🛜 WIFI Settings	Currently Connected to Will Network Adam's Home Network
🕛 Jess	80≋ ⊕	ð.,	
		System Settings	the stand



Turbo Zone



For high volumes of conditioned air in a single zone.

AirTouch's Turbo Zone feature can cool or warm a single zone quickly; or can be useful when there is a lot of activity and you need more conditioned air than normal.





Tap on **Turbo Group** and a drop-down menu will appear. Select which room you want a larger volume of air.



If there is more than one system, multiple Turbo groups can be set.

Date/Time	Turbo Group	Group Name	Preferences	installers
	Turbo Group	UNIT1	Uning	
			Family	
	26	UNITS	Guest	

The Turbo function cannot be programmed. It is activated manually from the console when needed.



Setting up Favourites



AirTouch's Favourites feature allows you to save your climate control scenarios.





Create up to four **Favourite** presets. Select whether you want each zone ON or OFF.

Give your **Favourite(s)** option a name and you're good to go!

															*	Fa		х
F	avourit	e1		C	F	avou	rite2		DC		Fav	ourite	8		$) \subset$		Favourite	
		ourite	Nam	ne i	Day													
Living		ÖN					•	ON										
Study		ON																
					Di	iys:			Day			Day	ytime					-
q	w	2	е	3	r	•	t	<u>.</u>	У	82	u	7	i	1	0	1	р	•
ŧ	3	S		d		f		g		h		j		k		1		0
*	z	ŝ	x		с		v		b		n		m	Î	1		?	+
7123																	10	Q



Using ITC (Individual Temperature Control)

ITC Sensor & Button



Zone Button

• Press the button once to see if your Zone is ON or OFF

Blue Light = ON Red Light = OFF

 Press the button again to change between ON or OFF

Replacing The battery

Remove the cover. Push the battery in the direction of the arrow on the pcb board. (as shown in the diagram on page 17)

2

When replacing the battery, press and hold the Zone Button (2) after removing the dead battery for 5 seconds to remove any residual charge from the circuit.

After replacing a battery you may need to pair the ITC sensor with AirTouch again.

The battery (3) used is 3V CR2450.

When the battery is low, a *Low Battery* icon (
) will appear near the zone name of the sensor.

A good battery will last for around 1 $\frac{1}{2}$ to 2 years.

When the battery is flat, the zone will change to % control if there is no other sensor in it.

Pairing ITC Sensors with AirTouch

On the AirTouch console open the **Quick Menu** and select System Settings > Installer > Sensors > Turn Sensor Pairing from Stop to Start.

By default, the installer password is Polyaire.

2

After removing the cover from the ITC sensor, push and hold the Pairing Button (2) for 5 seconds until the LED (1) turns blue (zone on) or red (zone off)

The zone name will appear on the sensor page of AirTouch 4 when the pairing is successful.





AirTouch 4 App

The AirTouch 4 App can be downloaded free of charge.



Install the AirTouch 4 App through the Apple App Store or Google Play Store.

After downloading the application, follow the prompts to link to your AirTouch console.

AirTouch 4 is compatible with:

- iOS 8.0 and above
- Android 4.0.3 and above



We are constantly adding new Smart Home integrations to AirTouch to enhance the system's capabilities and your home living experience.

To learn more, and see how to set them up, visit **airtouch.net.au**.











NOTE:

If a mobile device is connected to the same WiFi network as your AirTouch 4, the app will automatically direct you to the control interface. Alternatively, if you are unable to access the control interface, you will be prompted for the AirTouch ID and password to continue. The AirTouch ID can be found in the Preferences section on the console.

When away from home the app will connect to AirTouch using your phones' 3G or 4G connection.



System Settings

AirTouch Console Android OS Functions

You can leave the AirTouch 4 Application and use the Android OS by swiping up from the bottom of the console to open the Android navigation bar and pressing the home button.

The following settings are configured through the Android OS:



Note: Some of the Apps shown here are not preloaded

You can install any available Android Apps to your console to enhance the smart hub capability such as automated lighting or security systems as well as any lifestyle or entertainment Apps.

Disclaimer:

We cannot offer support for third party applications installed to, or modifications to the general settings of the Android OS installed on your AirTouch Console. While unlikely, installing third party applications, modifying the settings of or updating the Android OS of the AirTouch 4 Console may cause AirTouch to dysfunction.

Naming your Zones

*Zones are referred to as Groups in System Settings.

Customise AirTouch's Zone Names to suit your home



2

Select **Group Names** and edit individual **Groups** by tapping on the space provided to enter information.

To make it easy a preset name can be selected by selecting **Name List**.



Screen Lock

The Screen Lock Protects your Air Conditioning and AirTouch from potential damage caused by children playing with the console. It is set from within the Android OS.

> Swipe up from the bottom of the console to open the Android navigation bar. Press on the Home button and Tap on Settings.



Go to Security and find the **Screen Lock**. It is set to None in default.





Select 'Screen Lock' and follow the prompts to set it up.

Security	
Device security	
Screen lock Pattern	
Make pattern visible	
Make pattern visible	

Now, when the console goes to sleep and turns blank, you can unlock it using a password.



Owner's Name

Owner's Name is used by the mobile app to distinguish between AirTouch 4 systems.

The maximum length for a name is 16 letters.



2

Select **Preferences** and edit **Owner's Name** by tapping on the space provided to enter your details.



Temperature Display

*ITC Feature Only

If you have ITC, you can choose to see the actual temperature of each zone in the home screen.





2

Select **Preferences** and turn ON or OFF **Temperature Display** on the home screen.

To record all System Settings

Press **Save Settings to File** button. If the main module has been replaced, the system can be recovered from this file.

Balance & Grouping Tables

(Filled in by your installer)

Group	Group Name	Zones Included	Sensors	Turbo Function	Balance
1					
2					
3					
4					
5					
6					
7					
8					
9					
A					
в					
с					
D					
E					
F					
G					



WiFi & Internet Setup



How to connect AirTouch 4 to a home router, which will enable the control/operation of AC unit and zoning via local WiFi and internet.





Software Updates

Please make sure the AirTouch 4 is connected to the home router which has internet access. If there is a red dot on the top right corner of Quick Menu, a new version software is available for update. Follow the red dot and prompts to update the system. If the update fails, please try it again.

Remote Internet Control

For remote AC control over the internet, ensure Internet Access is ticked under **System Settings > Preferences**.

Local Access Password Protection

When enabled, mobile devices connected to the same WiFi Network as AirTouch will need to use the Internet Access password to use the App.



Hotspot

If AirTouch doesn't have access to the internet, you can still control it locally over WiFi with the AirTouch App by using the console as a WiFi Hotspot.

To setup AirTouch as a Hotspot, go to WiFi Settings, More> Tethering & Portable Hotspot> Portable WiFi Hotspot.

Turn it on and set a password which will also be used as the Local Access Password Protection password. You can then connect your smart devices to this WiFi Hotspot to control AirTouch using the App.

Favourite Apps

AirTouch 4 console also acts as a home hub where you can access all your favourite apps.



Just tap on the AirTouch logo and it will take you to your **Favourite Apps** page.



Tap on the specific app to run it. To exit, tap on the triangle on the navigation bar. To close the window, tap X.





Tap on Manage the List and you will see:

- Left side Your Favourite Apps you want to access quickly. Just tap on the Apps to remove them.
- Right side All Apps installed on the console.
 To add to the Favourite list, tap on the apps and it will move to the left side.

To exit the page, tap on the X button. It will take you to the **Favourites List**.

		urite Applications	~
U Lounge	Favourite Applications	Installed Applications	^
Dining	O Amazon Alexa	Chrome	
3 Family	🛆 Home	Clock	
(i) Line int		ConfigUpdater	
()		Contacts	
U Josh		O Downloads	
U Jess		ES File Explorer	
🛈 Guest	Click.ite	File Manager	
U) study	O OFF (D ***	10 Per	Midea-Carrier Service Touchpart2 Samsung:Service-AC
	⇒ ¢	< 0 □	<₽

Note:

When you first install AirTouch 4, the Favourites List will be empty.

Troubleshooting

Problem meets solution.

Problem	Suggested Action			
LED in the lower right corner flashes	No communication between the console and main module. Check if the AirTouch 4 App is running and the wiring.			
quickly	Disconnect the cable to the touchscreen and connect it back. Or power off the main module of the AirTouch4 and power it back on in a minute.			
LED flashes slowly (Every one second)	AC has an error. Either AC is faulty or the communications between AC and AirTouch 4 is lost. Call technician to further investigate.			
No LED light	No power to the console.			
Dampers have no response when turned on or off	Check if LEDs on the main module light up for relevant zones when the zone dampers are being turned On/Off. If Green/Red LEDs are not activated for the respective zone, the main module may be faulty, replace it.			
	If there is response, there might be a faulty cable and the cable would have to be replaced. If the zone is still non-functional then there might be a faulty damper motor.			
	Check if the cable from touch-pad to the main control module is faulty. If it is a faulty cable, then replace the cable.			
	Check Grouping and find out if the right zones have been assigned to the right groups and have been turned ON/OFF in Zoning section.			

Some zones cannot be turned off	Check if 'Spill' status is displayed for the zone. Opening other zones will rectify the error *Check spill groups.
No display on the LCD	*Check if the cable is plugged in properly. Unplug the cable and reconnect it. *Check if there is power to the unit.
LCD Display Corrupted	Reset LCD by holding RESET button on the right side of the console for 2s. If error is still not resolved, reset console by unplugging the cable from behind and then reconnect it after about 15 seconds. If the corrupted display remains, power off/on the console. Otherwise, replace the console.
WiFi symbol 奈 disappeared from the touchpad	After a power failure, AirTouch 4 will re-connect to home router and WiFi icon (♠) will be back on in 3 minutes from Power ON. Turn the wireless router OFF and turn it back ON. Wait for 3 minutes for the AirTouch 4 system to initialise. If WiFi icon (♠) does not appear, follow WiFi setup process to re-establish connection between your home router and AirTouch 4.
The reaction of the AT4 app on the console is slow after the app has been running for a long time.	Close the app and re-open the app. This needs to bring up the Android navigation bar at the bottom, press the left arrow button to close the app. Then restart the app.
"AC ERRORxx" is on touchpad	This error is displayed due to a fault with the AC unit. The AC ON/OFF function will be disabled when this error is displayed. The xx is the error code. Touch the error code to bring up description of the error. Please call AC technician quoting the error code.

Specifications

Electrical Requirements

Power supply:	24V AC ±10%
Line frequency:	50 Hz

Environmental Requirements

Operating Temperature:	0°C to 60°C
Altitude:	0 to 2000 meters
Operating relative humidity:	10% to 80%

Avoid static electricity hazards

Avoid electromagnetic radiation sources

Avoid dust contamination

Avoid highly corrosive environments



Zone Output

Output voltage:

Current:

24VAC, 50Hz 200mA (1 damper motor)

Transformer

Input Voltage:	240VAC, 50Hz
Output Voltage:	24VAC, 50Hz
Wattage	40W
Supply Air Sensor	NTC type, 10 kΩ at 25°C
Battery (Wireless Sensor)	3.0V, CR2450
Fuse	Dimension 5x20 mm
	Fast-Acting 2A, 250V





1300 980 656

airtouch4

Liability and Disclaimer

All specifications and procedures are correct at time of publication, but are subject to change without notice. Please read the instructions before installing this Zone Control System. Polyaire Pty Ltd does not accept any responsibility for loss or damage that may occur as a result of the incorrect installation or operation of this AirTouch Control System.

Polyaire Pty Ltd 11-13 White Road Gepps Cross South Australia, 5094 Tel: (08) 8349 8466 Fax: (08) 8349 8446

© Polyaire Pty Ltd 2019





Subscribe to us on YouTube at 'AirTouch'